

RAKU-AUTO

Electric Drum Pump Model FP-25

OPERATION MANUAL

For Kerosene and Diesel
application only

Contents

Safety Caution1

The name of parts
and specifications4

How to use
& care for pump5

Maintenance & Check6

Spare Parts List7

Trouble shooting and
maintenance9

For After Sales Service10

- Thank you for purchasing Koshin Electric Drum Pump. This product is used for the transfer of kerosene or diesel from drum.
- This operation manual is designed to caution you for the safe usage and operation of this product.
Please read carefully before use and understand how to operate.
Wrong usage may cause accident or injury.
- Please keep this manual for future reference.
- In case of inspection for repair, please contact your local distributor or dealer.
Please do not try to repair pump yourself.

For reasons of improvement, specifications are subject to change without notice.



KOSHIN LTD.

12 Kami-Hachinotsubo Kotari, Nagaokakyo City, Kyoto 617-8511 JAPAN
TEL.+81-75-954-6111 FAX.+81-75-954-6119

www.koshinpump.com

004034202

KOSHIN LTD.
www.koshinpump.com

SAFETY CAUTION

Read this "SAFETY CAUTION" carefully before use.
These following cautions are for correct usage of product and prevent you or others from injury or harm.

Each article contains important contents. Following are the articles:

 **DANGER** may cause death or serious injury.

 **WARNING** may cause death or serious injury.

 **CAUTION** may cause serious injury or major damage.

 This mark means "**PROHIBITION**"

 This mark means "**EXECUTION**"

It is necessary to follow the article.


DANGER

  **This product is for kerosene or diesel application only.**
This product cannot be used for petroleum grade liquid, such as gasoline, A-crude, solvents, Chemicals, water. (danger - may cause explosion, fire, or damage)

  **This product does not use flame-proof motor.**

  **Do not use this product near inflammable objects such as petrol.**

  **Do not use fire when you operate this product. It may cause fire.**

  **This product is exclusively designed for transfer of kerosene or diesel only. Do not use for other applications.**

SAFETY CAUTION

WARNING

  **Do not leave the pump unattended during operation.**

  **Do not operate this product without understanding the operation manual.**

  **Operate this product in a safe place away from children.**

  **Besides trained technician of repair, do not dismantle, repair, rebuild. It may cause damage.**


  **Do not wet the product with water or oil. It may cause serious accident, injury, or, damage to the product due to electric shock, short-circuit, or electric leakage.**

  **Please do not use outdoor.**
This product may be damaged if wet by rain or water.

CAUTION

  **Do not harm, damage, twist or break electric cable. Do not put heavy objects on the cable. This may cause damage to the cable and may cause fire, electric shock.**

  **Do not use this product if electric cable or electric plug is damaged or inadequate connection with power supply. It may cause electric shock, short-circuit or fire.**

  **Besides rated voltage, do not use this product. It may cause fire, electric-shock.**
Please do not allow too many wiring from one socket. It may cause overheat or cause voltage power to be reduced.


  **Do not dismantle the product. It may cause electric-shock or injury.**

SAFETY CAUTION

! CAUTION		
PROHIBITION		Do not give any shock to the product during operation. It might cause fire by electric-shock, short-circuit or electric leakage.
EXECUTION		If the product does not operate or looks like an abnormal run, take off electric cable immediately from socket, and ask for checking or repair with your local distributor/dealers.
PROHIBITION		Please do not run dry. (Operation without liquid in drum) It may cause damage to the product.
EXECUTION		Use this product with liquid temperature between 0 - 40 degrees centigrade.
EXECUTION		In case of extension power cord, please use cable with more than 1.25mm ² (for 15A) and use only necessary length. If thin or long power cord is used, it may lead to inferior performance or even damage the product.
PROHIBITION		When lifting the product, please do not pull power cord or hose. It may damage the power cord or hose.

* All these important safety instructions described by this operation manual may not cover all the conditions and cases of usage. We pay careful attention about safety of the product. Please pay careful attention by user, operator, technician for maintenance as well.

THE NAME OF PARTS AND SPECIFICATIONS




Model	FP-25
Type	FP-25-BAA
Connection Dia	25 mm (1")
Total Head	3.5 m
Delivery Volume	20 L/min
Voltage	AC 220 V 50/60Hz
Continuous Operating Time	30 min
Power Cord	4 m
Fuse	4 A
Delivery Hose	1.5 m
Nozzle	Gun type
Net Weight	2.7 kg

※ For FP-25 users, we offer 3M delivery hose as option item. 3M delivery hose is replacement type.

HOW TO USE


- 1 Insert suction pipe into Drum.
Fix Drum screw onto the collar.
Turn Drum Nut to fix.



⚠ Caution After fixing the pump to the drum, please do not operate pump or drum at oblique condition.

⚠ Caution When you loosen "Drum Nut", hold the pump body by another hand. Otherwise, pump body may drop suddenly and cause injury or damage.

- 2 Make sure Power Switch is "OFF" and Lever Lock of Nozzle is released, then, connect power plug.



- 3 Put Power Switch "ON" and grip the Lever of Nozzle.

- 4 If you use Lever Lock, pump will transfer oil continuously.
Release lever lock when stop continuous operation.

⚠ Danger If do not release the lever lock, the outflow of oil does not stop. To avoid a oil overflow, please operate carefully

⚠ Danger Do Not be near fire during operation

⊘ Prohibited When Power Switch is "ON" and motor is running, please do not leave pump with Lever Lock for more than 3 minutes. (It might cause damage or accident.)

CAUTION AFTER USE

1. After using pump, switch power to "OFF". Release Lever Lock of Nozzle, then, remove electric plug from socket.

2. Remove pump from the drum. Remove oil in the suction pipe, hose, and nozzle. Wipe off excess oil on the surface of the pump with a duster.

⚠ Caution After use, do not put pump on the ground directly. If dust gather at the strainer, it may cause future inferior suction or damage.

3. Storage
Please keep pump clean, in low humidity, well-ventilated, indoor, away from sunlight.


⚠ Caution Please lay down the pump during storage to avoid inversion.

CAUTION AFTER USE

4. Clean Strainer if you do not use this pump for long time.
(Refer Maintenance, Check)

⚠ Caution

If position of nozzle is lower than liquid level in the drum, liquid may leak from nozzle due to Siphon phenomenon. Put out this pump from drum before storage.



MAINTENANCE · CHECK


⚠ Caution

During maintenance and check, always turn switch to "OFF" and remove electric plug from socket. Otherwise may cause accident or injury.

【Cleaning of Strainer · Impeller】

If dust obstruct Strainer or Impeller, it may cause inferior suction, inferior flow, shorten pump's life and damage of motor. Make sure electric plug is removed from socket and check following points regularly.

- ① Remove Strainer by turning towards indicated direction, remove all dirt and dust.
- ② Remove Casing and clean up dust inside the Impeller.
- ③ After cleaning, re-assemble by reverse course.



【Replacement of Fuse】

A fuse may burn out to protect motor damage if surplus current enters the motor. It is necessary to replace a fuse in this case.


- ① Remove fuse cover by + screw driver, turn anti-clockwise rotation.
- ② Remove fuse, check if it is "burn out" then, replace with new 4A fuse.
- ③ Please re-assemble by reverse course.



⚠ Caution

In case of frequent fuse burn out, it may be other causes. Please refer "TROUBLE SHOOTING AND MAINTENANCE".

PARTS LIST



PARTS LIST

No.	Parts Code	Parts Name	Qty	Details
1	0048051	Pump Assy	1	No.2~14
2	0040283	Strainer	1	POM
3	0040328	Filter	1	SUS304
4	0040282	Casing	1	POM
5	0048055	Motor Assy	1	POM
6	0040281	Pump Casing	1	POM
7	0040316	Suction Pipe Packing	2	NBR
8	0048054	Suction Pipe Assy	1	No.9~10
9	0040280	Suction Pipe A	1	PE
10	0040279	Suction Pipe B	1	SUS304
11	0220210	Cord Grommet	1	NBR
12	0040291	Sp Body	1	POM
13	0040347	Drum Screw	1	POM
14	0040348	Drum Nut	1	POM
15	718605035	ϕTapping Screw M4X12L	4	M4x12 SUS
16	0048060	Power Unit Assy	1	No.17~41
17	718505037	ϕTapping Screw M4X16L	4	M4x16 SUS
18	0040321	Spacer	4	POM
19	0040294	Power Source Base	1	PA6
20	0040326	Tube 2X32	2	ϕ2x32
21	0048059	Trans	1	
22	0520047	Led(Light Emitting Diode)	1	
23	941900080	Band 3X80	1	3x80
24	0220907	Band 4X120	1	4x120
25	0040325	Tube (For +) ϕ3X60	2	ϕ3x60
26	0040289	Power Cord	1	VCT 1x2Cx4M
27	0040324	Tube (For -) ϕ3X140	1	ϕ3x140
28	0040351	Caution Label	1	
29	004029501	Cover For Power Source	1	PA6
30	004029601	Top Cover	1	PP
31	718605035	ϕTapping Screw M4X12L	2	M4x12 SUS
32	004034402	Name Plate	1	
33	004034601	Switch Label	1	
34	004805001	Fuse Assy	1	4A
35	004032901	4A Fuse	1	
36	0040327	Tube ϕ2X50	2	ϕ2x50
37	0451420	Switch Rubber	1	
38	0451405	Toggle Switch	1	
39	0040318	Cushion Rubber	1	NBR
40	0220607	Insulated Terminal	1	EC-1-1
41	0040323	Dc Cord For Power Source	1	PVC
42	0220607	Insulated Terminal	2	EC-1-1
43	0040373	Hose Cap	2	POM
44	0040383	Delivery Hose(1.5M)	1	PE
45	0048053	Nozzle Hose Assy	1	No46~56
46	0040302	Nozzle Packing	1	NBR
47	889855005	O-Ring P5	2	NBR
48	0040301	Nozzle Lever	1	POM
49	888705005	E-Stop Ring	1	SUS
50	0040306	Nozzle Weight	1	POM
51	853228137	Rivet 3X22	1	ALUMINIUM
52	0040307	Nozzle Hook	1	SUS
53	0040384	Nozzle Main	1	POM
54	0040304	Nozzle Spring	1	SUS304WPB
55	0040303	Nozzle Valve	1	POM
56	0040299	Nozzle End	1	POM
57	0040342	Operation Manual	1	


TROUBLE SHOOTING AND MAINTENANCE

Condition	Possible Cause	Measure
No discharge (No suction) Pump does not work	Dirt & dust inside pump	Open pump and clean
	Burn out Fuse * In such case, power lamp is light "ON"	Replace fuse * Check the cause of burn out of fuse and measure for it.
	Voltage drop when using extension cord	Reduce extension cord length
	Motor does not run	Ask repair by local distributor / dealer
	Electric plug does not sit well Into the socket (Check power lamp is light "ON" or not.)	Check electric plug And socket.
	Disconnection of power cord (Check power lamp is light "ON" or not.)	Ask repair by local distributor / dealer
No delivery (No suction) or, small delivery volume - pump is working.	Air-Lock inside pump	Turn power switch to "Off" and re-start A
	Hose is too long (in case of extension)	Shorten the hose.
	No liquid, not enough flow In the drum	Fill liquid into the drum
	Strainer is clogged with dust	Cleaning
	Bending hose	Straighten hose
Oil leakage	Loose screw Inferior seal packing	Tighten screw
Oil leakage from connection part of hose	Hose cap is not tightened enough	Tighten hose cap firmly
Oil leakage from nozzle	Leakage due to Siphon phenomenon	Remove liquid inside hose and keep position of hose higher than the pump before storage B




Caution Please do not dismantle or repair the pump by yourself.
Please ask for repair work from your local distributor /dealers.

A First, put the pump into drum and then, make the switch ON.



B If position of nozzle is lower than liquid level in the drum, liquid may leak from nozzle due to Siphon phenomenon. Put out this pump from drum before storage.



MEMO