



High Performance Submersible Pump

PONSTAR

PB SERIES OPERATION MANUAL

Thank you for choosing Koshin Submersible Pump.
This manual is prepared for your safety when operating pump.
Please read carefully and comprehend fully before use.
(Wrong usage could cause injury or death.)
Please keep this manual handy for future reference.

PLEASE READ THIS MANUAL BEFORE OPERATION.

"ACCEPTABLE FOR INDOOR OR OUTDOOR USE" "SUBMERSIBLE PUMP"

⚠ CAUTION ⚠

Before use, please make sure to read the instruction manual.
Do not operate the pump out of water or insufficient water.

⚠ WARNING ⚠

Risk of electric shock. This pump is supplied with a grounding conductor and grounding-type attachment plug. To reduce risk of electrical shock, connect only to a properly grounded, grounding-type receptacle.
TO REDUCE THE RISK OF ELECTRIC SHOCK, INSTALL ONLY ON A CIRCUIT PROTECTED BY A GROUND-FAULT CIRCUIT-INTERRUPTER (GFCI).

⚠ NOTE ⚠

This pump has not been investigated for use in swimming pool or marine areas. This pump has been evaluated for use with water only.

KOSHIN LTD.

www.koshinpump.com

12 Kami-Hachinotsubo Kotari, Nagaokakyo City, Kyoto 617-8511 JAPAN
TEL.+81-75-954-6111 FAX.+81-75-954-6119

- 1 -

09-07 043047003

INSTALLATION AND USE

- An acceptable motor-control switch shall be provided at the time of installation. Thermally protected

INSTRUCTIONS FOR USE

1. Please check the type, aperture, output, frequency, and voltage indicated on the name plate attached to the upper part of the pump.
Pay close attention, in particular, to frequency and voltage as inadequate frequency and voltage can cause lower pump performance and troubles.

2. Place to use

The pump can be used at almost all places but avoid continuous short-water operation at a sandy place, as such may accelerate wear of the pump.
Try to install the pump at a position where water can be collected most easily.
When the pump is installed on soft muddy or sandy ground, lay wooden board or block under the body to prevent setting down. Strictly refrain from putting into any pond bath, or swimming pool in which anybody is staying.

3. Hose piping

When any hose is used for connection, keep the hose as straight as possible as excessively bent hose reduces water quantity.
Refrain from placing the discharge port under water. Inverse flow may sometimes be resulted due to siphon effect when the operation is stopped.

4. Cabtire cable

To transfer the pump or to install, hold the pump on the handle or a rope tied to the handle. If the cabtire cable is pulled instead of the rope, the core wires may sometimes be cut off. To extend the cable, use a cable of the same or larger size than the one attached to the pump. Strictly refrain from placing the joint between the main line and the extension in water.

5. Earth leakage breaker

Be sure to ground the earthing wire before connecting the cabtire cable to the power source. The green wire is for earthing. Be sure to attach the leakage breaker to prevent any possible leakage trouble.

- 3 -

⚠ CAUTION

1. Leak Current Breaker

For home use, attach a leak current breaker, GFCI (offered separately) to ensure safety.

2. Connect the power source

Absolutely refrain from connecting this pump to any other power source than 110V AC, 50Hz.

3. Water to use

* Absolutely refrain from using the pump for any oil, sea water, strong alkaline or strong acidic solution, or any agricultural chemicals.

4. Do not run dry!

Idling can cause trouble, to prevent short cycling place pump at deepest position as possible.

5. Handling of power cord (cabtype cable)

- a. Never lift or move pump by power cord.
Only lift by handle or tie rope supplied to handle.
- b. Select and use proper size extension cord.
Do not run extension cord in water.

6. Using in bath, etc.

Do not enter the water when pump is being used.


⚠ CAUTION

The pump is used a double mechanical seal.
(See figure)

Consulting the following table assemble it.

Mechanical seal	Motor side (Carbon)	Plum side (Carborundum)
Outside diameter	22.5mm	20.5mm
Internal diameter	18.5mm	15.0mm

Double mechanical



- 2 -

6. After use

If the pump is left as it is after used for water of high sand content or other special substances, the sand is accumulated in the pump and will affect the next operation. Before stopping operation, therefore, be sure to keep pumping supernatant water or clean water for some time to clean out the inside.

7. Thermal protector

The pump incorporates a thermal protector to protect the motor, and the motor is stopped automatically at a over-load operation due to any reason. When the motor stops automatically, be sure to check after turning off the power source.

AFTER USING PUMP

1. In cold climates, do not allow pump to freeze.
Remove pump from water to prevent damage due to freezing.
2. Completely drain and dry pump of water before storing.

MAINTENANCE AND INSPECTION

1. Periodically check the insulated condition with a insulation resistance tester.
To be acceptable, the resistance between the earthing wire and the power cord should be 100Meg ohm and higher
2. The shaft of the water-tight mechanism as the most critical part of the pump is sealed with liquid paraffin. The life changes greatly depending on the operating condition but the quantity should be checked periodically.
Use 170cc of Crystol No.70 by Exxon Mobil Corporation for the sealing.
The liquid paraffin can be checked easily by removing the hexagon socket head bolt at a side of the pump body.

- 4 -

TROUBLESHOOTING GUIDE


PROBLEM	POSSIBLE CAUSE	SOLUTION
No start at all or stops immediately after start	Not properly connected to power circuit	Correct the connection
	The GFCI, leakage circuit breaker is actuated	Check the power circuit
	The impeller is caught by foreign substance	Repair the point of leakage
	Motor is burnt	Repair or replace
	Voltage drop	Raise the voltage to the rating
Failure during operation	The protector is actuated	Remove foreign substance if the impeller is clogged
		Lower the liquid temperature if it is too high
No pumping or poor performance	Voltage drop	Raise the voltage to the rating
	High delivery head	Lower the head
	Discharge pipe is clogged	Overhauling
	Impeller wear	Replacement
	Clogging of foreign matter in strainer pump	Overhauling

SPECIFICATIONS


MODEL		PB-65011	PB7-65011
PUMP	Connection Dia	2" (50 mm)	
	Total Head	32.8 ft (10 m)	55.7 ft (17 m)
	Delivery Volume	76.6 USG/min (290 L/min)	89.8 USG/min (340 L/min)
MOTOR	Voltage	Single AC-110V	
	Frequency	60 Hz	
	Rated Current	8.7 A	12 A
	Output	400 W	750 W
	Consumption	750 W	1.25kW
	Revolution	3400 rpm	
	Model	Induction Motor	
	Power Cord	19.7 ft (6 m)	32.8 ft (10 m)
Standard Accessories		1 Rope 5 m, 1 Hose Band	
Net Weight		35 lbs (16.7 kg)	42 lbs (19 kg)

*Starting current is three times higher than rated current.

DIMENSION



PERFORMANCE CURVE



*Performance ratings are guaranteed minimum, not inflated maximum.
**Starting current is three times higher than rated current.

Unit: mm										
MODEL	A	B	C	D	E	F	G	H	I	J
PB-65011	398	72	326	φ181	NPT	6000	84	43	44	74
PB7-65011	384	52	332	φ193	2"	10000				

PARTS LIST

