


NOTES FOR PULLING THE STARTER



- Pull the starter slowly until you feel resistance. Then, pull it quickly and firmly from that point to let the rope extend further.

If you don't pull hard enough (so the engine turns too slowly), the engine might not start.

- With the choke knob pulled out, pull the starter no more than three times.

Pulling it more than this may make starting the engine more difficult.